

Dear Customer,

We would like to thank you for buying this KEDO product. Please note the following instructions.

Have a safe ride and take care.

Yours KEDO Team

Assembly Instructions for Decals

Decals, as our XT500 Replica side covers, fuel tank decals etc. are easily affixed "wet" considering the following procedure:

1. Please have the decals spread flat at room temperature a few hours before applying.
2. The surface to be laminated must be clean and free of grease. Decals and areas to be laminated must be at room temperature.
3. Use a clean spray bottle (e.g. KEDO 51537), fill it with 500ml/0.13 gallons of water and add a few drops of dishwashing detergent. Alternatively you can use a bowl for the "soapy water".
4. Spray the mixture generously on the area to be laminated. If you used a bowl in step 3 you can also use a soft sponge or cloth to apply the soapy liquid.
5. Remove the carrier foil carefully from the back of the decal and apply the "soapy water" on the adhesive surface generously.
6. Place the decal on the surface to be laminated. Please do NOT press too tight yet.
7. Align the decal on the surface. It should be "floating".
8. After finding the right position, press the decal tight in the center and wipe out the liquid (e. g. with a clean, soft cloth or a squeegee with felt edge (KEDO 62024)). Tiny remaining bubbles will disappear after some time. Please do not lance them.
9. We strongly recommend to varnish the laminated areas with clear coat, as the decals are not resistant to solvent nor fuel (e. g. KEDO 51166).

